



iHip Fold-up Portable Speaker Battery Replacement

Use this guide to learn how to replace old or faulty batteries.

Written By: Cristina Garcia



INTRODUCTION

Follow these easy steps for battery replacement. This includes how to remove the battery case cover, clean the battery case, and replace the batteries.



TOOLS:

- [Detailing Brush](#) (1)



PARTS:


- [AAA batteries](#) (1)

Step 1 — Removing the battery case cover



- 1. Place the device on a flat surface as shown.
- ⓘ The battery case cover is found at the bottom of the device.
- 2. To remove the battery case cover, push down gently and slide the cover in the direction that the arrows indicate.

Step 2 — Cleaning the battery case



- 1. Remove and discard the old batteries.
- 2. Use the detailing brush and a paper towel to remove any corrosion left by previous batteries.

Step 3 — Inserting new AAA batteries



- Insert batteries with the "-", or dull side, facing the springs.
- ⓘ If you are replacing the stand, you'll insert the batteries last.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 12:45:23 PM.